




Single phase electronic flow switch. It automates the operation of a pump by sensing the water movement. Requires natural flow by gravity.



Roof tank installations

Basement installations (aqueduct)



FLUX starts and stops the pump on which it is installed, conveniently replacing the traditional pressure switches/autoclave systems.

### **OPERATION**

FLUX is an electronic pump control specifically designed to automate the start / stop of BOOSTER pumps.

When opening a tap, thanks to the pressure present in the system, even with the pump stopped, a small flow is created; as soon as it exceeds the cut-in flow rate FLUX it detects the flow and starts the pump, ensuring the necessary pressure in the system.

In case of leakages (small continuous flow rates lower than cut-in flow rate) FLUX does not start the pump, avoiding unnecessary energy consumption.

#### **TECHNICAL DATA**

- Voltage: 230/110 Volt a.c. Frequency: 50-60 Hz
- Maximum current: 12/16 A
- Protection degree: IP 65
- *Operating Temperature:* 0 65 ° C
- Connections: 1 "BSP / 1" NPT Working / bursting pressure10 Bar /> 40 Bar

### **ADVANTAGES**

Thanks to its high-performance check valve, FLUX is able to **start** the pump at very low flow rates (1-2<sup>1</sup>/min).

• FLUX can be installed horizontally, vertically or in any position respecting the flow direction.

• FLUX protects the pump from dry running, with auto-reset.

• FLUX is equipped with tropicalized electronic board

• FLUX is equipped with status LEDs and a stop and reset button.

• FLUX does not require any maintenance.

# **FEATURES**

Tropicalized electronic board. Easily replaceable, available in versions with: - voltages: 220 V / 110 V - frequencies: 50 Hz / 60 Hz

- currents: 12 A / 16 A



## FEATURES

**3 PIECES UNION** integrated

Avoiding the need of

expensive

3 pieces unions.

NON-RETURN VALVE built-in and inspectionable

**PRESSURE GAUGE** easy-to-add

Housed in the IP 65 enclosure,

easy to access for wiring, it is

tropicalized for absolute

Electronic board 12 A Electronic board 16 A

against humidity.

Check valve unit

protection

Spare Parts:




Avoid the need to install one




**OPTIONAL:** it can be added anytime.


### Simplicity of use.

A single button and 2 LEDs that indicate, with different colors and flashes, the status of the pump (presence of voltage / pump run / alarm status.



	Max. Current I max (A)		Voltage Frequency Volt / Herz
	12	16	230/50-60
FLUX FL 12	•		•
FLUX FL 16		•	•





.com 69717



DGFLOW srl Via Emilia, 5 - 46030 Bigarello (Mantova) Italy tel. +39 0376 340922 - fax. +39 0376 249525 info@dgflow.it - www.dgflow.it